MENYSTRUKTUR BS-100 *DYFI*

Versjon P1-BS100-3-20

- Hovedmeny
  - Ut/im-kobling
    - Utkobling
      - Adresse
      - Sone
      - 1) Styringer
        - BT-utganger (AUX,DHM)
        - Styringer (1-240)
      - 3) Klokker
      - Brannvesen (BMA, BMFO, BMF)
    - Innkobling
      - Adresse
      - Sone
      - Styringer
        - BT-utganger (AUX, DHM)
        - Styringer
      - Klokker
      - Brannvesen (BMA, BMFO, BMF)
  - Vis status
    - Alarm
    - Forvarsel
    - Adr./sløyfefeil
    - Systemfeil
    - Utkoblinger
    - Alarmteller
    - Hendelseslager (150 siste)
  - Test
    - Lampetest
    - Melding brannvesen (BMA, BMFO, BMF)
    - Feil
    - Alarmklokker
    - Summer
  - System
    - Følsomhet
      - Adresser
        - Enkeltadresse
      - Utenfor grense
        - Sløyfe
        - Total
          - Skriver
          - Display
      - Nedsmusset
        - Skriver
        - Display
    - Intern
      - Programversjon
      - Still klokke
      - Vis klokke
    - 2) Konfigurasjon
      - Komm.port
        - Sentraladr.
        - Alarminfo
      - Forsinkelse
        - Alarmvarsel (T1)
        - Tillegg (T2)
      - BU-enheter
      - DYFI-endringer
        - Alarm
        - Forvarsel
        - Filter
      - Batterispenning
      - Personsøker
  - 1) Data
    - Endring
      - 1) Endring av display og skrivertekster.
      - 2) Endring av styreutgang, alarmutgang og gruppe-utkobling.
    - Tillegg
    - Utskrift
      - Detektor data
      - Skrivertekst
  - Papirmating
  - 2) Service
    - Rapport
      - DYFI-tall
        - Enkeltadresse
      - 'Varm'-starter
        - Hovedprosessor
        - Sløyfeprosessor
        - Nullstill
    - Utkobling
      - Sløyfe
      - Summer
      - Skriver
    - Innkobling
      - Sløyfe
      - Summer
      - Skriver
    - Test
      - Adresse i alarm
      - Styringer
        - Styringer
        - BT-utganger(AUX,DHM)
    - Adresse kontr.
      - Sløyfe
        - Fra detektor
        - Fra front
    - Datakontroll
      - Overf. komm.port
        - Ja
        - Nei

Velg "RET" for å gå ett nivå opp i menystrukturen.
Velg "HM" for å returnere til hovedmenyen.

1) Passordbeskyttet på nivå 1 (Betjeningsnivå)
2) Passordbeskyttet på nivå 2 (Servicenivå)
3) Kan være passordbeskyttet.

P-BS100MEN/MAX, 971210

MENU STRUCTURE BS-100 *DYFI*

Version P1-BS100-3-20

- Main menu
  - Out/in-control
    - Disable
      - Address
      - Zone
      - 1) Controls
        - BT-outputs (AUX,DHM)
        - Controls (1-240)
      - 3) Sounders
      - Fire brigade (BMA,BMFO,BMF)
    - Restore
      - Address
      - Zone
      - Controls
        - BT-outputs (AUX, DHM)
        - Controls
      - Sounders
      - Fire brigade (BMA, BMFO, BMF)
  - Show status
    - Alarm
    - Prewarning
    - Addr./loop fault
    - System fault
    - Disablements
    - Alarm counter
    - Stored events (last 150)
  - Test
    - Front panel (lamp test)
    - BMA, BMFO, BMF
    - Fault
    - Sounders
    - Buzzer
  - System
    - Sensitivity
      - Addresses
        - Single address
        - Loop
        - Total
          - Printer
          - Display
      - Beyond limit
      - Polluted
        - Printer
        - Display
    - Internal
      - Program-version
      - Adjust clock
      - Show clock
    - 2) Configuration
      - Comm.channel
        - Panel addr.
        - Alarm info
      - Silence alarm (Alarm delay)
        - T1
        - T2
      - BU-units (display units)
      - DYFI-changes
        - Alarm
        - Prewarning
        - Filter
      - Battery voltage
      - Pocket-pager
  - 1) Data
    - Changes
      - 1) Changing of display and printer texts.
      - 2) Changing of output controls, alarm outputs and disabling groups.
    - Add
    - Print out
      - Detector data
      - Printer text
  - Feed paper
  - 2) Service
    - Report
      - DYFI-factors
        - Single address
      - Restart
        - Main prc. (processor)
        - Loops (processor)
        - Clear
    - Disable
      - Loop
      - Internal buzzer
      - Internal printer
    - Restore
      - Loop
      - Internal buzzer
      - Internal printer
    - Test
      - Address in alarm
      - Controls
        - Controls
        - BT-outputs (AUX,DHM)
    - Address control
      - Loop
        - From detector
        - From front
    - Data control
      - Transfer comm.port
        - Yes
        - No

Select "RET" to go 1 step back in the menu structure.
Select "MM" to return to main menu.

1) Password protected on level 1 (Operator level)
2) Password protected on level 2 (Service level)
3) May be password protected.

P-BS100MEN/MAX, 971210