AutroVoice BR-45

Features

- Compact voice-warning system for small-tomedium-sized applications
- Monitored Pre-recorded messages
- Pre-configured
- Easy installation and commissioning
- Monitored Emergency power (internal 38Ah battery with charger)
- Simple user interface
- Monitored Fireman's microphone with zone selection
- Manual/automatic activation/deactivation of pre-recorded messages
- Facilitates effective evacuation/information
- Complies with BS 5839.8 and EN 60849



The Autronica Fire and Security voice-alarm system AutroVoice BR-45 provides a compact solution for voice warning.

Voice warnings provide obvious advantages over other alarm types, ensuring that panic is avoided and clear evacuation instructions and updates are given.

BR-45 is a complete system incorporating emergency power and hot standby amplifier, making this a good choice in critical applications.

AutroVoice BR-45 complies with BS 5839.8 and EN 60849, showing that this product has the necessary capabilities to provide safe, reliable operation in emergency situations.

A major feature of this compact system is simple installation, commissioning and maintenance; this means that the system can be up and running in a short space of time, providing trouble-free operation.



Technical Specifications

Monitored 2x150W amplifier

Monitored 1x150W hot-standby amplifier

4 Monitored speaker circuits

8 spoken messages saved on monitored built-in MP3 module

Monitored Fireman's microphone with zone selection

Manual start/stop for pre-recorded messages

Monitored external trigger for messages


Input for music source


Input for external equipment 0-100V

Input for paging microphone with zone selection




Dimensions





Part number	Description
116-BR-45	Voice alarm system
116-APS-305	Digital microphone with zone selection
116-BR-210/45	Operator panel for BR-45

Connections



Terminals	
1-3	Relay output for fault
4-6	Relay for indication of active Evacuation or Alert
7-8	External trigger input for Alert
6a-8	External reset of Evacuation
9-10	External trigger input for Evacuation
11-14	Auxiliary input, 0,8-100V sound signal
15	Control (input level adjustment for terminals 11-14
20-24	Microphone input, APS-305 Digital microphone
25	DIN-5 Jack, Music input (-10dB)
30-36	Output amplifier 1 for zones 1 and 2, and direct 1
40-46	Output amplifier 2 for zones 3 and 4, and direct 2
Mains power	2AT fused mains (external) with backup fuse (internal)