

Menu Structure – Ver. 3.8.0

Integrated Fire & Gas



Access Level ≥ 2: Access by key.

Access Level 3: Key and password restricted.

- (1) Show Status
 - (1) Alarms
 - (2) Alarm Warnings
 - (3) Faults
 - (4) Disablesments
 - (5) Detection Zones in Test
 - (6) Inhibited Points
 - (7) Activated Outputs

- (1) Detection Zones
- (2) Points
- (3) Fire Alarm Devices
- (4) Fire Alarm Routing Equipment
- (5) Outputs
- (6) Fault Warning Routing Equipment
- (7) Immediate Output Actioning
- (8) All

- (1) Door Control Units
- (2) Low Location Light Units
- (3) Standard Control Units
- (4) Other Outputs
- (5) Fire Alarm Devices
- (6) Fire Alarm Routing Equipment
- (7) Fault Warning Routing Equipment
- (8) All

- (2) Disable
 - (1) Detection Zones
 - (2) Points
 - (3) Fire Alarm Devices
 - (4) Fire Alarm Routing Equipment
 - (5) Outputs
 - (6) Fault Warning Routing Equipment
 - (7) Immediate Output Actioning

- (1) Single Unit
- (2) All in Alarm Zone
- (1) Single Output
- (2) All in Operation Zone

- (3) Enable
 - (1) Detection Zones
 - (2) Points
 - (3) Fire Alarm Devices
 - (4) Fire Alarm Routing Equipment
 - (5) Outputs
 - (6) Fault Warning Routing Equipment
 - (7) Immediate Output Actioning

- (1) Single Unit
- (2) All in Alarm Zone
- (1) Single Output
- (2) All in Operation Zone

- (4) System
 - (1) Date and Time
 - (2) Information
 - (3) Access Level 3
 - (4) Printer
 - (5) Change Language
 - (6) Initialise
 - (7) Day / Night Timers

- (1) Enter Access Level 3 - Password
- (2) Leave Access Level 3
- (3) Set Password
- (4) Paper Feed

- (5) Service
 - (1) Start
 - (2) Stop
 - (3) Show Running Timers

- (1) Test
 - (1) Detection Zone Test (EN 54)
 - (1) Enter Test Mode
 - (2) Leave Test Mode
 - (2) Output Test
 - (1) Manual Test On
 - (2) Manual Test Off
 - (1) Alarms
 - (2) Prealarms
 - (3) Early Warnings
 - (4) Faults
 - (5) Disable / Enable
 - (6) User Operations
 - (7) Tests
 - (8) All Events
 - (9) Log Setup
 - (1) Clear Topology
 - (2) Disable Loop
 - (3) Enable Loop
 - (1) Read Parameters
 - (2) Read Filter
 - (3) Clear Log
 - (1) Fire Alarm Devices
 - (2) Fire Alarm Routing Equipment
 - (3) Fault Warning Routing Equipment
 - (4) Other Outputs
- (2) Log
- (3) Loop Commands
- (4) Oil & Gas Commands
- (5) Report
- (1) SV-Fault
- (2) Polluted
- (1) Inhibit Point
- (2) Cancel Inhibit Point
- (3) Set Alarm Limits
- (4) Get Measurement Values